



Business Mobility (IP) DECT DECT G277/577 Handset User Manual



Disclaimer

NEC reserves the right to revise or make changes or improvements to the products described in the user manual or to this user manual itself at any time without obligation to notify any person of such revision or improvements.

Revision history

May, 2019

First version

Contents

Contents

Introduction.....	10
Notice on the use of the handsets.....	10
SOS functions	10
Getting started	11
Installing the battery pack.....	11
Installing the charger	11
Charging the batteries.....	12
Charging a spare battery	12
Charging guidelines.....	12
Charging and operating times.....	12
Charge display	13
Handset keys and display areas.....	14
Handset keys.....	15
Display	17
Icon line.....	18
Time & Date area	19
Dialogue area	19
Idle mode	19
Call mode	19
Dialogue mode	20
Menu mode	21
Edit mode	21
Soft key line.....	23
Used notation in this manual.....	24
General functions	27
Switching the handset on	27
Switching the handset off	27
Key lock.....	27
Locking	27
Unlocking.....	27
Call features	28
Make a call.....	28

Contents

Dialling a number	28
Using Predial mode	28
Using Central or Private Directory ¹	28
Using Speed dial	29
Making an emergency SOS call (G577)	29
Answering a call	29
Answering a call in Normal mode	29
Answering a call using any key	29
Auto-answering mode	30
Muting the ringer of an incoming call	30
Rejecting an incoming call	30
Change settings during a call	30
Adjusting the headset or loudspeaker volume	30
Using mute during a call	30
Transferring a call	31
Dialling second destination then transfer	31
Using Private or Central Directory then transfer	31
Shuttle the call	32
Calls list	33
Actions on the calls lists	34
Open Calls list	34
Checking the details of a call	34
Dialling the number of the call list entry	34
First edit then dial the number of the call list entry	35
Transferring a name/number to your contacts list	35
Add a number to an existing contact	37
Transferring a number to the caller filter list	38
Deleting an entry	38
Deleting all entries	39
Contacts	40
Adding a new contact	40
Changing information of a contact	41
Deleting a contact	41
Deleting all contacts	42
Speed dial feature	42
Adding, replacing or deleting a speed dial contact	43
Adding contact to the caller filter list	44
Messaging (G577)	45
Normal, urgent and emergency messages	45
Normal messages	45
Urgent messages	45

Emergency messages	45
Confirming receipts	46
Message list full	46
Message Menu Sections	46
Open Message menu section	47
Actions on the messages	47
Reading a message	47
Writing and saving a new/draft message	48
Writing and sending a new/draft message	48
Forwarding a message	51
Replying to an incoming message	51
Deleting a message	52
Deleting all messages	52
Saving sender to the contacts list	53
Add sender to existing contact	53
Message settings	54
Calendar (G577)	55
Open the Calendar	55
Changing the calendar format (week or month view)	55
Open schedule for today	55
Open schedule for a given date	55
Adding an appointment	56
Open appointment	58
Editing an appointment	58
Copying an appointment	59
Deleting an appointment	59
Additional features (Accessories) (G577)	60
Calculator	60
Stopwatch	61
Alarms (alarm clock)	62
Open Alarms	62
Assigning or change a daily alarm	62
Turning off a daily alarm	62
Assigning or change a recurrent alarm	63
Turning off a recurrent alarm	63
Setting snooze time	64
Telephone settings	65
Open Settings menu section	65
General settings	66
Setting Silent	67
Setting the time and date	67

Contents

Setting the language	69
Configuring shortcuts	69
Configuring the LED signal	70
Security options	71
Setting the Phone lock feature	71
Setting the Automatic keypad lock feature	72
Changing the PIN code	72
Changing the Proxy password	73
Defining the handset name	74
Resetting settings	74
View status information	75
Sounds (normal & silent) settings	76
Incoming call	78
Message notifications	80
Setting the notification volume	80
Setting the notification melodies	84
Setting the increasing notification feature	84
Setting the vibrator feature	85
Alerts	86
Feedback	88
Display settings	90
Selecting Wallpaper	90
Selecting startup screen	91
Configuring power save	91
Calls settings	93
View statistics information	94
Answer mode configuration	94
Caller filter configuration	95
Configuring emergency or SOS calls (G577)	100
Assigning emergency call number	100
Assigning an emergency message	102
Assigning the Silent charging feature	102
Defining the missed call time	103
Voicemail	103
Assigning the Voicemail number	104
Connectivity settings	105
DECT system selection	105
Bluetooth settings (G577)	106
Enable Bluetooth	106
Disable Bluetooth	107
Pairing a Bluetooth headset	108
Connecting a paired Bluetooth headset	108

Disconnecting a paired Bluetooth headset.....	109
Renaming a paired Bluetooth headset.....	110
Retrieve information for a paired Bluetooth headset.....	111
Delete a paired Bluetooth headset.....	112
Delete all paired Bluetooth headsets	113

Introduction

Also refer to the following documents:

- Additional Information Sheet
- G277/577 Quick Reference Guide

Notice on the use of the handsets

Like all cordless telephones, the G277/577 DECT handset uses radio signals, which do not guarantee a connection under all circumstances. Do not rely exclusively on the DECT handsets when making indispensable calls (such as medical emergencies).

SOS functions

The SOS functions of the G577 do not replace companion supervision by a colleague or other people. In case of critical, emergency or life-threatening situations make sure that other persons are present or that appropriate measures are taken.

Getting started

Installing the battery pack

1. Place the handset face down on a flat surface.
2. Slide the lock at the bottom of the battery compartment cover upwards and at the same time lift the cover away from the handset.
3. Remove the battery compartment cover.
4. Push the battery pack into the casing.
5. Replace the battery cover.

Installing the charger

1. Place the charger on a flat surface.
2. Connect the USB-C connector of the USB cable to (the back of) the charger.
3. Connect the type A USB connector to the USB AC/DC Adapter.
4. Connect the adapter to an electrical outlet.
5. Place the handset on the charger as shown in [Figure 1](#).



Figure 1: G277/G577/G577h in Desktop Charger

Getting started

Charging the batteries

Place the handset in the charger as shown in [Figure 1](#). For a few seconds the display of the handset shows:




Figure 2: Battery charging display

<i>Attention:</i>	The handset, if switched off, automatically switches on when placed in the charger.
--------------------------	---

Charging a spare battery

The G277/577 Spare Battery Desktop Charger can be used to charge a spare battery pack for the G277/577. To charge a spare battery pack:

1. Place the spare battery pack in the spare battery charging slot compartment. (Upside down and with text on the battery pack facing to the front.)
2. Slide the spare battery pack under the plastic holder to keep it in place.

Charging guidelines

Please read the concerning section in the DECT Handsets – General Information Guide carefully!






Charging and operating times

Discharged batteries require 7 hours (using the spare battery slot might take longer) to completely recharge. Completely charged batteries provide the handset with up to 20 hours of talk time and 160 hours of standby time.

Charge display

The battery charge status appears on the top of the display screen:

Table 1: Battery charge status icons

Icon	Charge status
	Almost empty
	Less than 10%
	10% to 20%
	20% to 90% (the bigger the green bar, the higher the charged percentage)
	Fully charged (more than 90%)

When the battery is nearly discharged a warning beep sounds and, when not in a call, the display shows:




Figure 3: Battery low display

You cannot make calls while this message appears.

Getting started

Handset keys and display areas



Figure 4: Elements of the G277/577 (Front View)














Figure 5: Elements of the G277/577 (Side Views)









Handset keys

Table 2: Keys of the Handset

Key		Description
LEFT SOFT KEY		Key related to the action given on the bottom left of the display.
MIDDLE SOFT KEY		Key related to the action given on the bottom middle of the display.
RIGHT SOFT KEY		Key related to the action given on the bottom right of the display.
UP		Use the navigation keys to: <ul style="list-style-type: none"> – Select the required menu icon or menu element; – Navigate the cursor; – In some cases change (increase/decrease) a given value; – Access the shortcut assigned to it.
DOWN		
LEFT		
RIGHT		
OK		Used to acknowledge menu selection.
CALL		Used to go off hook and to initiate enquiry/hold/shuttle.
CLR		Use the Clear key to <ul style="list-style-type: none"> – Release a call;

Getting started

Table 2: Keys of the Handset

Key		Description
		<ul style="list-style-type: none"> – Return to the previous step in a menu; – Switch your handset off (long press) – Switch your handset on.
SPEAKER		Used to go off hook and initiate enquiry using hands free.
MENU		Used to access main menu items.
SOS (G577)		Long press the SOS key to make an emergency call (if configured).
VOLUME UP		To increase the handset volume.
VOLUME DOWN		Decrease the handset volume.
1–9	 	Use 1 – 9 to <ul style="list-style-type: none"> – Insert a digit in a number; – Insert a character; – Select a Speed dial number
0		Use 0 to <ul style="list-style-type: none"> – Insert a 0 in a number; – Insert a character.




Getting started		
*		Use * to <ul style="list-style-type: none"> – Insert a * in a number; – Insert a character – Insert a decimal point (Calculator feature).

Table 2: Keys of the Handset

Key		Description
#		Use # to <ul style="list-style-type: none"> – Insert a # in a number; – Switch between Normal and Silent (sounds & alerts) settings by long pressing (more than 2 seconds) the key. – Toggle the character case (capital, lower case or digit) when in edit mode.
LINE KEY		Use one of the four Line keys to <ul style="list-style-type: none"> – Select a Speed dial number – Access the shortcut assigned to it.

Display

Figure 6 shows the four areas of the display:

- Icon line
- Time & Date area
- Dialogue area
- Soft key line
















Figure 6: Display screen

Icon line

The icon line displays the status of the handset.

Table 3: Icon line icons

Icon	Description
	Level of radio signal (always shown)
	New text message received
	Voice message waiting indication
	Keypad locked
	Alarm set
	Missed calls
	Ring
	Ringer deactivated
	Caller filter active

	Pull cord activated
	USB connected
	Battery charge status Refer to Table 1 for Battery status icons.

Time & Date area

The Time & Date area is only shown in Idle mode and gives the current time and date. In any other mode this part of the display is added to the Dialogue area (see next).

Dialogue area

The Dialogue area displays information according to the operational mode of the handset:

Idle mode

In Idle mode, the dialogue area displays information like DECT system name, handset's DNR, and so on.



Figure 7: Idle mode screen

Call mode

In Call mode, the dialogue area displays information related to the call, like number and name of the calling/connected party and some status icons (see [Table 4](#) and [Table 5](#)).

Table 4: Call Set-up icons








Icon	Description
	Incoming call <i>One to three green “circles” intermittently shown</i>
	Outgoing call <i>One to three blue “circles” intermittently shown</i>

Table 5: Call Conversation icons

Icon	Description
	Call in conversation <i>Call set-up <u>by</u> this phone</i>
	Call in conversation <i>Call set-up <u>to</u> this phone</i>
	Loudspeaker on
	Microphone muted while loudspeaker on
	Microphone muted while loudspeaker off

Dialogue mode

In Dialogue mode, the dialogue area displays dialogues regarding missed calls (see [Figure 8](#)), messaging, menu settings, warnings and so on (see for some examples).




Figure 8: Examples Dialogue mode

Menu mode

In Menu mode, the dialogue area displays the menu icons or menu sections (tabs) and the specific menu items. E.g.:




Figure 9: Main menu and General setting menu

Edit mode

In Edit mode, you can use the dialogue area to enter and edit digits (e.g., for numbers) and text, e.g., for contact information editing:




Figure 10: Contacts name and number editing

Getting started

[Table 6](#) shows the key to press to insert letters, numbers or symbols.

Besides the physical keys also the **Symbol** soft key is used in the Edit mode to insert (symbol) characters.

Table 6: key functions in text mode

Key	Uppercase	Lowercase
1	1 . ! ? , - " @ + : :	1 . ! ? , - " @ + : :
2	A B C 2 Æ À Á Â Ã Å Ç	a b c 2 æ à á â ã ä å ç
3	D E F 3 È É Ê Ë	d e f 3 è é ê ë
4	G H I 4 Í Î Ï	g h i 4 í î ï
5	J K L 5	j k l 5
6	M N O 6 Œ Ó Ô Ö Ø	m n o 6 œ ó ô ö ø
7	P Q R S 7 Š Š ß	p q r s 7 š š ß
8	T U V 8 Ù Ú Û Ü	t u v 8 ù ú û ü
9	W X Y Z 9 Ÿ Ž ž	w x y z 9 ý ž ž
0	(space) 0	(space) 0
*	*	*
#	Toggle character case: Abc → ABC → abc → 123	
Symbol	. , ` ? ! " ' - () @ / : _ ; + & % * = < > £ (space) \$ ¥ ¢ [] { } \ ~ ^ ¡ § ¨ # ' ' '	

Soft key line

Soft keys appear below the handset dialogue area. The key functions change automatically according to the operational state of the handset.

Used notation in this manual



Main menu icons are used to indicate selection of the appropriate menu.




To select the appropriate main menu item use the **NAVIGATION** keys.




Off-white box with text indicates a selected menu item.

To select the appropriate menu item use the **UP** and/or **DOWN NAVIGATION** key.




White box with dark blue top containing text indicates some text or number needs to be given.

To supply the necessary information use the keypad and the **NAVIGATION** keys.



Dark box with question mark indicates a question that the user needs to answer to.

To supply the answer use the appropriate soft key.



Press the indicated key.



The blue box with text indicates a soft key.



The three icons are special soft keys (available in the idle state).

Select the appropriate soft key to execute the indicated action:



Left soft key




Middle soft key



Right soft key



Use the keypad and/or the **NAVIGATION** keys to enter or change a number, date, name or text:

- Use the keypad to insert one or more digits (0 – 9, * and #) or characters
- To delete a digit or character use soft key 
- Use the Navigation keys to move the cursor to the insertion point
- Use the Up or Down Navigation key to increase or decrease the value of the selected field



Use (one of) the **NAVIGATION** keys



Use **LEFT** and/or **RIGHT NAVIGATION** key



Use **UP** and/or **DOWN NAVIGATION** key.

Getting started

n Press (soft) key displayed one or more times

Optional step(s): The following step(s) is (are) optional (and marked by a blue line), i.e.,

- they can be skipped by the user OR
- they are not offered to the user.

→ ❶ Used when the following actions (steps) depend on some condition. The condition is preceding the arrow, and the next action to be taken is marked by the indicated number (here: ❶).

All actions belonging to set of actions to be taken, are marked by an orange line at the beginning of the actions.

General functions

Switching the handset on

1. 

Switching the handset off

1.  > 3s
2. 

Key lock

Attention: You can dial 911 and 112 when the key lock is active.
The key lock does not affect the **SOS** key.

Locking

1. 
2. 

Also automatic keypad lock can be set from the Settings menu.

Unlocking

1. 
2. 

Also automatic keypad lock can be set from the Settings menu.

Call features

Make a call

Dialling a number

1. 
2.  Enter/edit: Number





Using Predial mode

1.   Enter/edit: Number
2. 




Using Central or Private Directory¹

1.  Or 

Optional step(s):

2.   Enter the first character(s) of the required name
3. 
4.  Select: required contact


Optional step(s):

5.  Select: appropriate number
6.  Or 

¹ Central Directory is only available if it is provided by your communication system or using the Central Directory Access Connector.

Using Speed dial

1.  ... 

Or  Long press (G577)


Making an emergency SOS call (G577)

See also [Configuring emergency or SOS calls \(page 101\)](#).

1. 

Answering a call

Answering a call in Normal mode

1.  Loudspeaker off



Or

1.  Loudspeaker on


Answering a call using any key

See also [Answer mode configuration \(page 95\)](#).

1.  ,  ,  ..  ,  ,  , Loudspeaker off

 Or 

Or

1.  Loudspeaker on

Auto-answering mode

See also [Answer mode configuration \(page 95\)](#).

To answer an incoming call no manual action is required.

Muting the ringer of an incoming call

1. 

Rejecting an incoming call

1. 

Change settings during a call

Adjusting the headset or loudspeaker volume

Volume up:



Volume down:



Adjusted volume setting is saved for future calls.

Using mute during a call

Deactivate the microphone (mute)

1. 

Activate the microphone (unmute)

1. 

Activate and deactivate the loudspeaker (toggle function)

1. 

Using the loudspeaker enhances the possibility that the speech is distorted. Therefore your DECT handset is no substitute for a conference device!

Transferring a call






Dialling second destination then transfer

1. 
2.  Enter/edit: Number





Optional step(s):

3.  Await answer
4. 




Using Private or Central Directory then transfer

1. 
2.   Or 
3. 

Optional step(s):`

4.   Enter the first character(s) of the required name
5. 
6.  Select: required contact

Optional step(s):

7.  Select: appropriate number
8.  Or 

Optional step(s):

9.  Await answer
10. 









Shuttle the call

To alternate between the two parties (before transfer):

1. 

Calls list

Table 7: Call type icons and Call type tabs

Call List	Call Type	
	Icon	Tab
All calls	-	 All calls
Answered calls		 Answered calls
Dialed calls		 Dialed calls
Missed call (unanswered or rejected)		 Missed calls (One combined list)
Missed call (Caller filter)		











Figure 11: Call lists

Calls list




Actions on the calls lists

Open Calls list

1. 
2.   =  =  =  = 




Checking the details of a call

Open Calls list:  Or  Or  Or 

1.  Select: required entry
2. 
3.  n

Dialling the number of the call list entry

Open Calls list:  Or  Or  Or 

1.  Select: required entry
2.  Or 


First edit then dial the number of the call list entry

[Open Calls list:](#)



1.  Select: required entry

2. 

3.  

4. 

5.   Enter/edit: Number

6.  Or 

Transferring a name/number to your contacts list

[Open Calls list:](#)



1.  Select: required entry

2. 

3.  

4. 

Optional step(s):

5.  

6. 

7.   Enter/edit: **Name**


Calls list


8.


Save


9.



Work: 

Mobile: 

Home: 

Other: 

10.

Add

Optional step(s):

11.



Enter/edit: Number


12.

Save

Optional step(s):

13.



Ringtone: 

Default

14.

Edit

15.



 Default

 Melody 1

:

:

 Melody 20


16.

Select

17.

Save

18.



Yes

19.



n

Add a number to an existing contact

Open Calls list:





1.  Select: required entry

2. 

3.  

4. 

5.  Select: required contact

6.  

7.  Or 

Optional step(s):

8.   Enter/edit: Number

9. 

10. 

11. 



12.  n

Calls list

Transferring a number to the caller filter list

[Open Calls list:](#)



Or



Or



Or



1.



Select: required entry

2.



3.



Save in caller filter

4.



Optional step(s):

5.



Enter/edit: **Name**



6.

7.



8.



n

Deleting an entry

[Open Calls list:](#)



Or



Or



Or



1.



Select: required entry

2.



3.



Delete item

4.



5.



6.



n

Missed calls list entries will also be deleted from the list if:

- You answer a call from the to the entry related number (entry moved to the **Answered** calls list).
- You dial the to the entry related number (entry moved to the **Dialed** calls list).

Deleting all entries

Open Calls list:



Or



Or



Or



1.

Select

2.



Delete all items

3.

Select

4.

Yes

5.



n

Contacts

Adding a new contact

1.



2.

More

3.



Add contact

4.

Select

5.



Name:



6.

Edit

7.



Name

Abc

8.

Select

9.



Work:



Mobile:



Home:



Other:



10.

Edit

11.



Work

Mobile














Home

Other

12.

Select

Optional step(s):

13.  
14. 
15.  
 
: :
: :

16. 
17. 
18. 

19.  n



Note: Currently set value is marked by a blue dot (●)

Changing information of a contact

1. 
2.  Select: required contact
3. 

Continue as in [Adding a new contact \(page 40\)](#) from step 5.

Deleting a contact

1. 
2.  Select: required contact

Contacts

3. 

4.  

5. 

6. 

7.  n


Deleting all contacts

1. 

2. 

3.  

4. 

5. 



6.  

7. 











8.  n

Speed dial feature

See also [Using Speed dial \(page 29\)](#).

Attention: Only the first number in the “chain” **Work**, **Mobile**, **Home** and **Other** assigned to the contact will be used by the **Speed dial** key.

Adding, replacing or deleting a speed dial contact

1. 
2.  Select: required contact
3. 
4.  
5. 
6.   → **① add**
 → **② replace**
 → **③ delete**

① add

7. 
8. 

② replace









7. 
8. 

③ delete

7. 
8. 

³ # = 2 .. 9, L1, L2, L3 or L4

Adding contact to the caller filter list

1. 
2.  Select: required contact
3. 
4.  Save in caller filter
5. 
6. 
7.   n

Messaging (G577)

Normal, urgent and emergency messages

The system differentiates between **Normal**, **Urgent** and **Emergency** messages.

Note: It is not possible to send an **Emergency** message from your DECT handset.

Normal messages

The melody assigned to **Notification normal** plays when you receive a normal message. If you receive a normal message during a call, a short alert tone sounds.

Urgent messages

The handset shows urgent messages immediately on the display.

The melody assigned to **Notification urgent** plays when you receive an urgent message. If you receive an urgent message during a call, a repeated short alert tone sounds.

Emergency messages

The handset shows emergency messages immediately on the display.

The melody assigned to **Notification emergency** plays when you receive an emergency message. The ringer volume increases to the maximum during the signaling process. If you receive an emergency message during a call, a repeated and in volume increasing short alert tone sounds.

Messaging

Confirming receipts


You must confirm the receipt of urgent and emergency messages. If you do not confirm the message within 60 seconds, the initiator receives a message that indicates the message was not delivered.

To confirm:

Positively:  Or 

Negatively:  Or 

Message list full







Attention:

If the display shows this warning no new message can be received. Delete some messages or change the **Overwrite old** setting to **On** – see [Message settings \(page 53\)](#).




Message Menu Sections

The **Messaging** menu contains a number of sections:

Table 8: Messaging Menu Sections

Description	Section
New and draft	 New and draft
Inbox	 Inbox
Sent messages	 Sent messages
Settings	 Settings





Open Message menu section

- 1. 
- 2. 
- 3. 
- 4.  =  =  =  = 

Actions on the messages

Reading a message

Open Message menu section: ,  Or 

- 1.  Select: required message
- 2.  Optional step(s):
- 3.  Scroll the text
- 4.  n

Messaging

Writing and saving a new/draft message

Open Message menu section:



1. **New** Or 1a.



Select: required message

2. 1b. **Select**



3.



4.



Yes

5. **n**



Writing and sending a new/draft message

Open Message menu section:



1. **New** Or 1a.



Select: required message

2. 1b. **Select**



3.

Send

4.




Normal

Urgent

5.

Select

6.
- 
- Contacts

Enter number

Send to many

Central directory
- 1

→ 2

→ 3

→ 4

1 Contacts

7.
- Select

8.
- 
- Select: required contact

9.
- Send

Optional step(s):

10.
- Yes

11.
-  n

2 Enter number

7.
- Select

8.
- 1 2 3
4 5 6
7 8 9
* 0 #



Enter number

9.
- Send


Optional step(s):

10.
- Yes


11.
-  n

Messaging

③ Send to many



④ Central directory



Forwarding a message

Open Message menu section:



Or



1.



Select: required message

2.



3.



4.



Optional step(s):

5.



6.

Continue as in [Writing and sending a new/draft message \(page 48\)](#) from step 3.

Replying to an incoming message

Open Message menu section:



1.



Select: required message

2.



3.



4.



5.



6.



Messaging








Optional step(s):

- 7. 
- 8.  n

Deleting a message

Open Message menu section:








- 1.  Select: required message
- 2. 
- 3.  
- 4. 
- 5. 
- 6.  n

Deleting all messages

Open Message menu section:



- 1. 
- 2.  
- 3. 
- 4. 

Yes

5.  n

Saving sender to the contacts list

[Open Message menu section:](#)



1.  Select: required message

2. 

3.  

4. 

5. Continue as in [Transferring a name/number to your contacts list \(page 35\)](#) from step 5.

Add sender to existing contact

[Open Message menu section:](#)



1.  Select: required message

2. 

3.  

4. 

5. Continue as in [Add a number to an existing contact \(page 37\)](#) from step 5.

Message settings


The following messaging options can be configured to **On** or **Off**:

- **Overwrite old** to control what happens when the handset receives a new message, but there is no room to store more messages:
 - **On**: the oldest message stored on the phone is overwritten.
 - **Off**: new message is not stored. An **Urgent** or **Emergency** message is shown on the display; a **Normal** message is rejected.
- **Sent messages** to control whether sent messages are stored in the handset (**On**) or not (**Off**).
- **Display** to control whether **Normal** messages are displayed immediately upon receipt (**On**) or not (**Off**).
- **Auto answer msg** – Please contact your System Administrator
- **Silent answer msg** – Please contact your System Administrator

Open Message menu section:



1.



Overwrite old

....

Sent Messages


....

Display

....

Or


Or
2.



On

Or

Off
3.

 n







Calendar (G577)

Open the Calendar

1. 
2. 
3. 


Changing the calendar format (week or month view)

[Open the Calendar](#)

1. 
2.  

3. 
4.  n






Open schedule for today

[Open the Calendar](#)

1. 
2.  
3. 
4. 


Open schedule for a given date

[Open the Calendar](#)

1. 
 2.  
 3. 
- 

Calendar

4.



5.



6.




Adding an appointment

Open the Calendar

1.




2.



3.




4.



5.



6.



1

7.



Go to step 12.

2

7.

Select

8.

1	2	3
4	5	6
7	8	9
*	0	#



End date

15 - 01 - 2013

Save

9.

Select

10.

1	2	3
4	5	6
7	8	9
*	0	#



End time

11 : 30

Save

11.

Select

12.

1	2	3
4	5	6
7	8	9
*	0	#



Subject

Project Meeting

abc 0 h : 4 i : 1

13.

Select

14.

1	2	3
4	5	6
7	8	9
*	0	#



Location

KOC140_

123

15.

Select

16.



At start

5 minutes

10 minutes

15 minutes

30 minutes

1 hour

Other → 4

3

3

17.

Select

18.




n

4

17.

Select


18.



19.

Select

20.



21.

Select

22.



n

Open appointment

Note: Days with appointments will be marked with a red dot at the bottom right of the date.

Open the day/date of the appointment using [Open schedule for today](#)/[Open schedule for a given date](#)

1.



Select: required appointment

2.

View

Editing an appointment

[Open appointment](#)





1.

Edit

2. Make the necessary changes like in [Adding an appointment \(page 56\)](#) from step 2.








Copying an appointment

[Open appointment](#)

1. 
2. 

3. 
4. Make the necessary changes like in [Adding an appointment \(page 56\)](#) from step 2.

Deleting an appointment

[Open appointment](#)

1. 
2. 

3. 
4. 
5. 
 n

Additional features (Accessories) (G577)

Calculator

When the **Calculator** is selected the following holds:



used to insert a decimal point



used to make a percentage of the given entry

Toggle

change the use of the **NAVIGATION** keys between:

- Mathematical operators
- Moving the cursor to the insertion point

1.



2.



3.

Select

4.



Calculator

5.

Select

6.



Enter/edit: a value

7.



Enter/edit: mathematical operator
(+, x, ÷ and -)

8.



Enter/edit: a value

9.





Calculate and show the result

10.







n

Stopwatch

1. 
2.  
3. 
4.  
5. 








Use of the stopwatch soft keys:

Table 9: Stopwatch soft keys

Soft key	Description
	Start a new measurement Or Continue a stopped measurement
	Halt the measurement
	Save the intermediate result and continue the measurement
	Reset the stopwatch (back to 0)










Alarms (alarm clock)

Open Alarms

- 1. 
- 2.  
- 3. 
- 4.  
- 5. 






Assigning or change a daily alarm

[Open Alarms](#)

- 1.   Assign new
 Change existing
- 2. 
- 3.   
- 4. 
- 5.  n

Turning off a daily alarm

[Open Alarms](#)

- 1.  
- 2. 
- 3. 
- 4.  n

Additional features (Accessories)

Assigning or change a recurrent alarm

Open Alarms

1.



Recurrent alarm
Off

Recurrent alarm
hh:mm

Assign new

Change existing

2.

Select

3.

1 2 3
4 5 6
7 8 9
* 0 #



Time

20

18 : 00

Save Turn off

4.

Select

For the required days of the week:

5.



☐ Sunday

:

:

☐ Saturday

Note: (Already) selected days are marked with ☒

6.

Mark

Or

Unmark

7.

Yes

Turning off a recurrent alarm

Open Alarms

1.



Recurrent alarm
hh:mm

2.

Select

3.

Turn off

4.




n

Additional features (Accessories)

Setting snooze time

Open Alarms


1.



2.



3.



:



Note: Currently set value is marked by a blue dot (🔵)

4.



5.









n






Telephone settings













The **Settings** menu contains a number of sections:

Table 10: Settings Menu Sections

Description	Section
General	 General
Sounds - normal	 Sounds - normal
Sounds - silent	 Sounds - silent
Display	 Display
Calls	 Calls
Connectivity	 Connectivity










Open Settings menu section


- 
-  
- 
- 

 General	=	
 Sounds - normal	=	
 Sounds - silent	=	
 Display	=	
 Calls	=	
 Connectivity	=	

General settings

Table 11: General setting

Item	Description	Page
 Silent	<ul style="list-style-type: none"> Switch to/from the silent “profile” 	67
 Time & date	<ul style="list-style-type: none"> Set the current Time & date 	67
 Language English	<ul style="list-style-type: none"> Set the Language 	70
 Shortcuts	<ul style="list-style-type: none"> Create Shortcuts to the handset menus and features (by pressing a navigation key) 	70
 LED signal	<ul style="list-style-type: none"> Assign a certain condition to one of the three LEDs 	71
 Security	<ul style="list-style-type: none"> Set the security settings: Phone lock, Automatic keylock, PIN Code and Proxy password 	72
 Handset name Empty	<ul style="list-style-type: none"> Set the Handset name 	75
 RFID	<ul style="list-style-type: none"> Set the RFID settings: Notification, Destination and Out of LF 	75
 Reset settings	<ul style="list-style-type: none"> Return settings to the factory values. Not affected are: Contacts, PIN Code, Proxy password and the system registrations 	77






 Status	<ul style="list-style-type: none"> View handset information 	77
--	--	--------------------

Setting Silent


If **Silent** is **On** the handset uses the sound definitions set with the **Sounds - silent** settings, otherwise it uses the **Sounds - normal** settings.

[Open Settings menu section:](#)



- 

-  Or 
-  n

Quickly toggle **Silent** setting:

-  Long press







Setting the time and date

Note: If your communication system provides the date and time, then setting the date and time has only a temporary effect and will, in due time, revert to the by the system provided time and date.

Setting the time

[Open Settings menu section:](#)



- 

- 
- 

- 

Telephone settings


5.






Optional step(s):

6.




7.




☒ 24 hour
☐ am/pm


8.



9.



10.


 n

Note: Currently set value is marked by a blue dot (●)

Setting the date


Open Settings menu section:

1.




Time & date

2.




3.






Date
22-01-2013

4.




5.






Optional step(s):

6.




7.



☒ dd-mm-yyyy
 :
 :
☐ yyyy-mm-dd

Note: Currently set value is marked by a blue dot (●)

8. 
9. 
10.  n

 Russian-2




Setting the language

Open Settings menu section:




1. 

 Language
English

2. 

3. 

 English
:
:
 Russian-2

Note: Currently set value is marked by a blue dot ()

4. 

5.  n

Configuring shortcuts

Shortcuts are used to get quick access to menu items.

Open Settings menu section:





1. 








 Shortcuts

2. 

3. 

 Left nav. key
.....
:
:
 Line key 4
.....

Telephone settings

4. 
5.  : 
 : 
6. 
7.  n

Note: Currently set value is marked by a blue dot ()











Configuring the LED signal

The **Red LED**, **Green LED** and **Yellow LED** can be used to indicate certain conditions to the user:

- Missed call
- Text message
- Voice message
- Text or voice msg
- Low battery
- Charging
- Silent charging


Open Settings menu section:



1.   
2. 
3.   


4. 

Telephone settings

5.



Note: Currently set value is marked by a blue dot ()

6.

Select

7.



n

Security options

Setting the Phone lock feature

If the **Phone lock** is set then upon turning on your handset you'll be asked to enter the **PIN Code**.

Open Settings menu section:




1.



2.

Select

3.



4.

Select

5.



6.

Yes

7.



Note: Currently set value is marked by a blue dot ()

8.

Select

9.



n

Telephone settings

Setting the Automatic keypad lock feature

Open Settings menu section:



1.



2.



3.



4.



5.



Note: Currently set value is marked by a blue dot ()

6.



7.



n

Changing the PIN code

Open Settings menu section:




1.



2.




3.



4.



5.



6.



Telephone settings

7.



8.

Yes

9.



10.

Yes

11.



Changing the Proxy password

Change the **Proxy password** that is used at SIP authentication.

Open Settings menu section:



1.



2.

Select

3.



4.

Select

Optional step(s):

5.



6.

Yes






7.



8.

Yes









Telephone settings

9.   
10. 
11.  n

Defining the handset name

[Open Settings menu section:](#)



1.  
2. 
3.   
4. 
5.  n

Resetting settings

All user determined **Settings** are set to the default factory values! [Open Settings menu section:](#)



1.  
2. 
3.   
4. 

Telephone settings

5.



6.



7.




n

View status information

Open Settings menu section:




1.



2.



3.



Note: In reality divided over three screens

4.



5.



n

Table 12: Sounds settings






Item	Description	Page
 Incoming call	<p>Sound settings related to an Incoming call:</p> <ul style="list-style-type: none">• Ring volume• Ring external melody for calls from an external source• Ring internal melody for calls from an internal source• Ring unknown call melody for calls from an unknown source• Group ring melody for calls from an group source• Intercom ring melody for calls from an intercom source• Emergency ring melody for calls from an emergency call source• ARB ring melody for calls from an automatic ring back source• Increasing ring to determine whether the Ring volume increases gradually• Vibrator to define the trembler feature for calls	<u>81</u>
 Message notification	<p>Sound settings related to an incoming message:</p> <ul style="list-style-type: none">• Notification volume	<u>83</u>

Table 12: Sounds settings

Item	Description	Page
	<ul style="list-style-type: none"> • Notification normal melody for Normal messages • Notification urgent melody for Urgent messages • Notification emergency melody for Emergency messages • Increasing notification to determine whether the Notification volume increases gradually • Vibrator to define the trembler feature for messages 	
 Alerts	Sound settings related to Alerts (for Calendar and Alarms): <ul style="list-style-type: none"> • Alert volume • Alert melody • Increasing alert to determine whether the Alert volume increases gradually • Vibrator to define the trembler feature for Alerts 	<u>86</u>
 Feedback	Sound settings related to: <ul style="list-style-type: none"> • Key sound for the sound that occurs when you press a key • Confirmation sound for the sound that indicates successful setting 	<u>88</u>
 Noise reduction	Configure the settings for Noise Reduction	<u>90</u>

Telephone settings

Incoming call











Setting the ring volume

Open Settings menu section:



Or



1.  
2. 
3.  
4. 
5.  Or 
6. 
7.  n










Setting the ring melodies

Open Settings menu section:




Or



1.  
2. 
3.  Or 
 Or 
4.  

Telephone settings

5.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

6.

Play

7.

Stop

8.

Select

9.



Setting the increasing ring feature


Open Settings menu section:



Or




1.



2.

Select

3.



4.

Off

Or

On

5.



Setting the vibrator feature


Open Settings menu section:



Or



1.



2.

Select

Telephone settings


3.



4.



5.



Note: Currently set value is marked by a blue dot (🔵)

6.



7.



Message notifications

Setting the notification volume

Open Settings menu section:




1.



2.




3.



4.



5.



6.



7.



Telephone settings

Setting the notification melodies

Open Settings menu section:



Or



1.



Message notification

2.

Select

3.



Notification normal
Melody n

Or

Notification urgent
Melody n

Or

Notification emergency
Melody n

4.

Select

5.



Melody 1

:

:

Note: Currently set value is marked by a blue dot (●)

Ringtone:
Default

Optional step(s):

6.

Play

7.

Stop

8.

Select

9.



n

Setting the increasing notification feature

Open Settings menu section:



Or



1.








Message notification

2.


Select











Telephone settings

3.  
4.  Or 
5.  n

Setting the vibrator feature

[Open Settings menu section:](#)



1.  
2. 
3.  
4. 
5.  
6. 
7.  n

Note: Currently set value is marked by a blue dot (●)

Telephone settings

Alerts












Setting the alert volume

[Open Settings menu section:](#)



Or



1.  
2. 
3.  
4. 
5.  Or 

6. 
7.  n







Setting the alert melody

[Open Settings menu section:](#)




Or



1.  
2. 
3.  
4. 

Telephone settings

5.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

6.

Play

7.

Stop

8.

Select

9.



n

Setting the increasing alert feature

Open Settings menu section:



Or




1.



2.

Select

3.



4.

Off

Or

On

5.



n

Setting the vibrator feature

Open Settings menu section:



Or




1.



2.

Select

Telephone settings





Note: Currently set value is marked by a blue dot (●)



Feedback

Setting the key sound feature

[Open Settings menu section:](#)










Note: Currently set value is marked by a blue dot (●)



Setting confirmation sound

[Open Settings menu section:](#)











2. 
3.  
4.  Or 
5.  n

Setting the coverage warning feature

Open Settings menu section:



Or

1.  
2. 
3.  
4.  Or 
5.  n









Setting the charger warning feature

Open Settings menu section:






Or



1.  
2. 
3.  
4.  Or 
5.  n

Display settings






Table 13: Display settings

Item	Description	Page
	<ul style="list-style-type: none">Select the image that is displayed on the screen of your handset in the idle state	91
	<ul style="list-style-type: none">Select the startup screen image which displays temporarily when the handset starts	92
	<ul style="list-style-type: none">Configure the periods of time after which the handset's display is dimmed and turned off	92

Selecting Wallpaper





For other **Wallpaper** than **Default**: Please contact your System Administrator

[Open Settings menu section:](#) 

1. 
2. 
3. 
- 
- 

Note: Currently set value is marked by a blue dot (●)

Optional step(s):






4. 
5. 
6. 
7. 

Selecting startup screen

For other **Startup screen** than **Default** or **NEC**: Please contact your System Administrator





Open Settings menu section:



1.  
2. 
3.  

Note: Currently set value is marked by a blue dot (●)

Optional step(s):

4. 
5. 
6. 
7.  n

Configuring power save

The display of your DECT Handset has three intensity levels:

- Display on;
- Display dimmed;
- Display off.






Figure 12: Display intensity levels On, Dimmed and Off

The various levels are used to save energy and are applied based


Telephone settings

on the **Power save** setting.

Open Settings menu section:




1.



2.



3.



To never turn off the display
set the second value to 0

4.











5.



n


Calls settings

Table 14: Calls settings

Item	Description	Page
 Units h:mm:ss nn	<ul style="list-style-type: none"> View information regarding outgoing Call time and Message count. 	95
 Answer mode	<ul style="list-style-type: none"> Determine how incoming calls can be answered: <ul style="list-style-type: none"> Normal using  Or  By pressing Any key Automatically (Auto answer) 	95
 Caller filter	<ul style="list-style-type: none"> Selectively block or accept calls from specified callers. 	96
 Emergency Call	<ul style="list-style-type: none"> Configure the Emergency call feature to dial a number or send a text message by long pressing the SOS key. 	101
 Silent charging	<ul style="list-style-type: none"> Determine what action is taken when the handset is called while in the charger. 	115
 Missed call time nn sec.	<ul style="list-style-type: none"> Determine when a not answered call is added to the Missed calls list 	116

Telephone settings







Table 14: Calls settings

Item	Description	Page
 Voicemail number Empty	<ul style="list-style-type: none"> Configure the Voicemail number 	116





View statistics information

[Open Settings menu section:](#)



-   Units
h:mm:ss nn
-  Select
-   Call time
h:mm:ss Or
 Message count
nn

Optional step(s):

-  Clear
-  ?
Do you wish to clear the selected counter?
-  Yes
-  n

Answer mode configuration

[Open Settings menu section:](#)



-   Answer mode
....
-  Select

Telephone settings

3.  ☐ Normal
-  ☐ Any key
-  ☐ Auto answer

Or
Or
Note: Currently set value is marked by a blue dot (●)

4.




5.  n

Caller filter configuration


Adding an entry to the Caller filter list

[Open Settings menu section:](#)




1. 
2.
3. 
4.
5.
6.  → ❶
 → ❷
 → ❸

❶ Lookup contact

7.
8.  Select: required contact
9.

Telephone settings

10.



11.




②

Enter number

7.



8.



9.




10.



11.



12.



13.



③

Central directory

7.



8.



Enter the first character(s) of the required name


9.



10.















Select: required contact

11. 
12. 

13.  n

Changing a Caller filter entry

Open Settings menu section:



1.  
2. 
3.  
4. 
5. 
6.  
7. 
8.  Select: required entry
9. 

Continue as in [Adding an entry to the Caller filter list \(page 96\).](#)















② - **Enter number**, from step 8

Telephone settings

Deleting an entry from the Caller filter list

[Open Settings menu section:](#)



















1.  
2. 
3.  
4. 
5. 
6.  
7. 
8.  Select: required entry
9. 
10. 
11.  n

Deleting all entries in the Caller filter list

[Open Settings menu section:](#)









1.  

2. 
3.  
4. 
5. 
6.  
7. 
8. 
Delete entire caller filter list?
9. 
 
10. 
11.  n


Activating Caller filter

[Open Settings menu section:](#)



1.  
2. 
3.  
4. 

Telephone settings

5. 

Accept list

Block list

Filter off

→ Accept only calls from callers in the **Caller filter**

→ Don't accept calls from callers in the **Caller filter**

→ **Caller filter** not used
- Note: Currently set value is marked by a blue dot (●)*

6. Select


7.  n


Configuring emergency or SOS calls (G577)


Assigning emergency call number

[Open Settings menu section:](#)



1. 

Emergency Call
....
2. Select
3. 

Number
....
4. Select
5. 

Lookup contact

Enter number

Central directory

→ ❶

→ ❷

→ ❸

❶ Lookup contact

6. Select

7.  Select: required contact

8. **Select**

9.  n

② Enter number

6. **Select**

7.  



When no number is entered then the **Emergency call** feature is disabled

8. **Select**

9.  n

③ Central directory

6. **Select**

7.  

Enter the first character(s) of the required name

8. **Yes**

9.  Select: required contact


10. **Select**

11.  n

Telephone settings

Assigning an emergency message

Open Settings menu section:



To make a voice call **no Emergency call** message should be defined.



Assigning the Silent charging feature

Open Settings menu section:



→ **Silent charging** not used

→ Disconnect from the system while in the charger¹⁴



→ Turn off the ringer (and vibrator) while in the charger

¹⁴ If configured: redirect call to alternative destination

Note: Currently set value is marked by a blue dot (●)

4. 

5.  n




Defining the missed call time

Open Settings menu section:



1.  

2. 

3.   

4. 

5.  n

Voice mail


Use the Voicemail feature to listen to voice messages left by calling parties¹⁵. You receive a voicemail in the following situations:

- if your handset is switched off
- if your handset is busy
- if your handset is out of the coverage area

A new voice message dialogue appears only once, i.e., when a caller leaves a first new message in the mailbox. A voicemail

¹⁵ Your communications system needs to support the Voicemail feature

Telephone settings

symbol () appears in the icon line; it disappears after you play the message.

Assigning the Voicemail number

[Open Settings menu section:](#)



1.



Clear

2.

Select

3.



Voicemail number

4.

Select





5.



n

Connectivity settings







Table 15: Connectivity settings

Item	Description	Page
	<ul style="list-style-type: none"> Register handset to a DECT system <p>Please contact your System Administrator</p>	-
	<ul style="list-style-type: none"> Remove registration your handset from a DECT system <p>Please contact your System Administrator</p>	-
	<ul style="list-style-type: none"> Select which DECT system is to be used (only if the handset is registered to more DECT systems) 	118
	<ul style="list-style-type: none"> Enable/Disable Bluetooth connectivity for pairing a Bluetooth headset. 	119

DECT system selection

[Open Settings menu section:](#)



- 

- 

- 


→ Handset selects DECT system automatically

Telephone settings

→ Select: required DECT system (here e.g., **NEC Hilversum**)




Note: Currently set value is marked by a blue dot (●)

4. 

5.  n

Bluetooth settings (G577)

Table 16: Bluetooth headset status

Icon	Description
	Connected
	Disconnected
	In conversation

Enable Bluetooth


Open Settings menu section: 

1.   Bluetooth

2. 


3.  

4. 



Disable Bluetooth

Open Settings menu section:



Telephone settings

Pairing a Bluetooth headset

[Open Settings menu section](#) and [Enable Bluetooth:](#) 



3. Start pairing mode on your Bluetooth headset – refer to your headset documentation.



Select: required headset
(e.g. BT 31R)



Headset **PIN Code!**











Connecting a paired Bluetooth headset

[Open Settings menu section:](#) 













Telephone settings

2. 
3.  
4. 
5.   Select: required headset
(e.g. BT 31R)
6. 
7.  n

Disconnecting a paired Bluetooth headset

Open Settings menu section:



1.  
2. 
3.  
4. 
5.   Select: required headset
(e.g. BT 31R)
6. 
7.  n

Renaming a paired Bluetooth headset

Open Settings menu section:



1.





2.



3.





4.



5.







Select: required headset
(e.g. BT 31R)

6.



7.






8.



9.







10.



11.



n

Retrieve information for a paired Bluetooth headset

[Open Settings menu section](#) and [Enable Bluetooth](#):



1.



Bluetooth

2.

Select

3.



Paired devices

4.

Select

5.



BT 31R

Select: required headset
(e.g. BT 31R)

6.

More

7.




Info

8.

Select

9.



10.

Yes

11.




n

Delete a paired Bluetooth headset

Open Settings menu section:



Select: required headset
(e.g. BT 31R)



Delete all paired Bluetooth headsets

Open Settings menu section:



1.



Bluetooth

2.

Select

3.



Paired devices

4.

Select

5.



BT 31R

Select: required headset
(e.g. BT 31R)

6.

Select

7.




Delete all

8.

Select

9.



10.

Yes

11.



n

THIS PAGE IS INTENTIONALLY LEFT BLANK